

# Roto

## NT Designo 2 Tilt & Turn (TBT) Striker Plates

Profile System	Profile Name	Sash No.	Frame No.	Casement Striker	Mushroom Striker	TBT Striker LH	TBT Striker RH	Add. Stay Packer	Turn Restrictor Frame Part	Pivot Rest LH/ RH	Stay Arm Range	Hinge Range	Sash Lift Striker
Aluplast	Ideal 70	SA77WF	OF50/60/75	5RNT1036	5RNT2042	5RNT0769	5RNT0770	5RNT1507	5RNT3114	5RNT3271/3272	5RNT3273-3278	K09	5RNT0517
Deceuninck	2500 Traditional	2537/2538	2532/2533	5RNT1006	5RNT2010	5RNT0709	5RNT0710	5RNT1510	TBA	5RNT3185/3186	5RNT3187-3192	K31	5RNT0515
Deceuninck	2800 Heritage	2828	2820/2821	5RNT1006	5RNT2010	5RNT0709	5RNT0710	5RNT1510	TBA	5RNT3185/3186	5RNT3187-3192	K31	5RNT0515
Deceuninck	3000 Contemporary	3041	3000/3002	5RNT1006	5RNT2010	5RNT0709	5RNT0710	5RNT1516	TBA	5RNT3185/3186	5RNT3187-3192	K31	TBA
Eurocell	Eurologik	EWS7707/7007	EWS7721/7021	5RNT1032	5RNT2023	5RNT0749	5RNT0749	5RNT1517	5RNT3118	5RNT3169/3170	5RNT3171-3176	K32	5RNT0506
Eurocell	Ultimate 70	EWS021	EWS007	5RNT1019	5RNT2021	5RNT0747	5RNT0748	TBA	TBA	5RNT3161/3162	5RNT3163-3168	K33	TBA
Halo	Rustique MK2	P10532	P10539	5RNT1009	5RNT2022	5RNT0701	5RNT0702	5RNT1516	5RNT3114	5RNT3137/3138	5RNT3139-3140	K13	5RNT0514
Halo	System 10 MK2			5RNT1009	5RNT2022	5RNT0701	5RNT0702	5RNT1516	5RNT3114	5RNT3137/3138	5RNT3139-3140	K13	5RNT0514
Kommerling	C70	7507	395	5RNT1034	5RNT2003	5RNT0729	5RNT0730	5RNT1517	5RNT3109	5RNT3185/3186	5RNT3187-3192	K31	5RNT0516
Kommerling	O70	2901	2910	5RNT1034	5RNT2003	5RNT0729	5RNT0730	5RNT1517	5RNT3109	5RNT3185/3186	5RNT3187-3192	K31	5RNT0516
Liniar		LCW/LSW035	LCW/LSW016	5RNT2012	5RNT2012	5RNT0709	5RNT0710	5RNT1507	5RNT3109	5RNT3201/3202	5RNT3203-3208	K28	5RNT0511
LB Plastics	8000			5RNT1033	TBA	TBA	TBA	TBA	TBA	5RNT3193/3194	5RNT3195-3200	K26	TBA
Profine	Legend 70	98-11501	98-11494/499/500	5RNT1010	5RNT2015	5RNT0723	5RNT0724	TBA	TBA	5RNT3247/3248	5RNT3249-3254	K23	TBA
Rehau	Total 70 IG*	546160	546180	5RNT1005	5RNT2009	5RNT0713	5RNT0714	5RNT1510	5RNT3109	5RNT3239/3240	5RNT3241-3246	K17	Use mishandling device
Rehau	Tritec	541430	503540	5RNT1005	5RNT2009	5RNT0713	5RNT0714	5RNT1510	5RNT3109	5RNT3239/3240	5RNT3241-3246	K17	5RNT0504
Sapa	Dualframe	Use 8mm Drive Gear		5RNT1020	5RNT2031 LH 5RNT2032 RH	5RNT0737	5RNT0738	TBA	TBA	5RNT3279/3280	5RNT3281-3286	K37	TBA
Selecta	Advanced 70	1753	1756	5RNT1005	5RNT2009	5RNT0713	5RNT0714	5RNT1517	5RNT3109	5RNT3303/3304	5RNT3305-3310	K39	5RNT0516
Spectus	Elite 63	A33	A01/02/03	5RNT1007	5RNT2011	5RNT0729	5RNT0730	5RNT1517	5RNT3109	5RNT3303/3304	5RNT3305-3310	K39	5RNT0508
Spectus	Elite 70	B38	B05/06/07	5RNT1007	5RNT2011	5RNT0729	5RNT0730	5RNT1517	5RNT3109	5RNT3303/3304	5RNT3305-3310	K39	5RNT0508
Stayfix				5RNT2002	5RNT2002	5RNT0745	5RNT0746	TBA	TBA	5RNT3331/3332	5RNT3333-3338	K40	TBA
Timber	13mm Axis/24mm Rebate			5RNT1031	5RNT2043 LH 5RNT2044 RH	5RNT0759	5RNT0760	TBA	TBA	5RNT3121/3122	5RNT3123-3128	H24	5RNT0513
Veka	FSS	103.267	101.267	5RNT1037	5RNT2047	5RNT0731	5RNT0732	5RNT1507	5RNT3109	5RNT3129/3130	5RNT3131-3136	K14	5RNT0506
Veka	New Matrix 70			5RNT1037	5RNT2047	5RNT0731	5RNT0732	5RNT1507	5RNT3109	5RNT3129/3130	5RNT3131-3136	K14	5RNT0506
Veka	Matrix 70	103.134/259	101.109/144	5RNT1003	5RNT2007	5RNT0705	5RNT0706	-	TBA	5RNT3263/3264	5RNT3265-3270	K25	TBA

\*Slim 8mm backset drivegear prevents breakthrough into glazing area. Some fabricators may still prefer to use 15mm BS