

Roto

NT Tilt & Turn (TBT) Striker Plates

Profile System	Profile Name/Notes	Sash No	Frame No	Axis	'A'	'K'	Casement Strike	Mushroom Strike	TBT Striker LH	TBT Strike RH	Sash Lifter Strike	Additional Stay Packer
Aluplast	Ideal 70	SA77WF	OF50/60/750	13	Y	N/A	5RNT1006	5RNT2010	5RNT0729	5RNT0730	5RNT1018	5RNT1507
Deceuninck	2500 Traditional	2537/2538	2532/2533	13	Y	Y	5RNT1006	5RNT2010	5RNT0709	5RNT0710	5RNT1018	TBA
Deceuninck	2800 Heritage	2828	2820/2821	13	Y	N/A	5RNT1006	5RNT2010	5RNT0709	5RNT0710	5RNT1018	TBA
Deceuninck	3000 Contemporary	3041	3000/3002	13	Y	N/A	5RNT1006	5RNT2010	5RNT0709	5RNT0710	5RNT1018	5RNT1516
Duraflex	Diamond 65	3004/3529	2900/3000/ 3522/3523	9	Y	N/A	5RNT1017	5RNT2014	5RNT0719	5RNT0720	TBA	TBA
Duraflex	Diamond 70	3004/3529	3542/3543/ 3517/3518	9	Y	N/A	5RNT1017	5RNT2014	5RNT0719	5RNT0720	TBA	TBA
Eurocell	Euro-Logik	EWS7707/7007	EWS7721/7021	13	Y	N/A	5RNT1032	5RNT2023	5RNT0749	5RNT0749	5RNT0506	-
Eurocell	Ultimate 70	EWS021	EWS007	13	Y	Y	5RNT1019	5RNT2021	5RNT0747	5RNT0748	456093	-
Halo	Rustique Mk 2	P10532	P10539	13	Y	N/A	5RNT1009	5RNT2022	5RNT0701	5RNT0702	260557	-
Halo	System 10 Mk 2			13	Y	N/A	5RNT1009	5RNT2022az	5RNT0701	5RNT0702	260557	-
Kommerling	C70	7507	395	13	Y	Y	5RNT1034	5RNT2003	5RNT0729	5RNT0730	260554	5RNT1516
Kommerling	O70	2901	2910	13	Y	Y	5RNT1034	5RNT2003	5RNT0729	5RNT0730	260554	5RNT1516
Liniar		LCW/LSW 035	LCW/LSW 016	13	Y	N/A	5RNT2012	5RNT2012	5RNT0709	5RNT0710	TBA	5RNT1511
Profile 22	FS70			13	Y	N/A	5RNT1003	TBA	5RNT0705	5RNT0706	TBA	TBA
Profine	Legend 70	98-11501	98-11494/499/500	13	Y	N/A	5RNT1010	5RNT2015	5RNT0723	5RNT0724	292199	-
Rehau	Total 70 - IG*	546160	546180	13	Y	N/A	5RNT1005	5RNT2009	5RNT0713	5RNT0714		Use mishandling device
Rehau	Tritec	541430	503540	13	Y	Y	5RNT1005	5RNT2009	5RNT0713	5RNT0714	5RNT0504	5RNT1510
Sapa	Dualframe	Use 8mm backset drive gear		9	N/A	N/A	5RNT1020	5RNT2031 LH 5RNT2032 RH	5RNT0737	5RNT0738	TBA	TBA
SAS	300/400/600	Use 8mm backset drive gear		9	N/A	N/A	5RNT2006	5RNT2006	5RNT0703	5RNT0704	5RNT0504	TBA
Selecta	Advance 70	1753	1756	13	Y	TBA	5RNT1005	5RNT2009	5RNT0713	5RNT0714		TBA
Spectus	Elite 63	A33	A01/02/03	13	Y	Y	5RNT1007	5RNT2011	5RNT0729	5RNT0730	5RNT0508	5RNT1510
Spectus	Elite 70	B38	B05/06/07	13	Y	Y	5RNT1007	5RNT2011	5RNT0729	5RNT0730	5RNT0508	5RNT1510
Swish	Twentyfour-seven			13	Y	N/A	5RNT1003	TBA	5RNT0750	5RNT0750	TBA	TBA
Timber	11/12mm		Flat Rebate	9	Y	N/A	5RNT1022	5RNT2027 LH 5RNT2028 RH	5RNT0739	5RNT0740	5RNT0509	N/A
Timber	11/12mm		7/8 Groove	9	Y	N/A	5RNT1016	5RNT2025 LH 5RNT2026 RH	5RNT0735	5RNT0736	5RNT0509	TBA

*Slim 8mm backset drivegear prevents breakthrough into glazing area. Some fabricators may still prefer to use 15mm BS

15/12/2021 E & OE. Details according to manufacturer's specification at the date the list is produced

©VBH

Roto

NT Tilt & Turn (TBT) Striker Plates

Profile System	Profile Name/Notes	Sash No	Frame No	Axis	'A'	'K'	Casement Strike	Mushroom Strike	TBT Striker LH	TBT Strike RH	Sash Lifter Strike	Additional Stay Packer
Universal	Aluminium	XEW02	XEW161	9	N/A	N/A	5RNT1021	TBA	5RNT0703	5RNT0704	TBA	TBA
Veka	FSS	103.267	101.267	13	Y	N/A	5RNT1037	5RNT2047	5RNT0731	5RNT0732	5RNT0506	TBA
Veka	New Matrix 70			13	Y	N/A	5RNT1037	5RNT2047	5RNT0731	5RNT0732	5RNT0506	TBA
Veka	Matrix 70	103.134/259	101.109/144	13	Y	Y	5RNT1003	5RNT2007	5RNT0705	5RNT0706	5RNT0505	-